


BENCHTOP DRILL PRESS

Operating Instructions



Extra drive belt included.

BENCHTOP DRILL PRESS

Operating Instructions

PRODUCT CHARACTERISTICS


This small, lightweight drill press is uniquely designed for small precision applications. The single phase, adjustable speed motor allows for control and ease of use.

SPECIFICATIONS

- 110 volt
- 100 watt
- Jacobs Chuck
- Max drill bit diameter: 6mm
- Max travel: 1"
- Max distance between work platform and chuck: 8"
- Weight: 11lbs.

ASSEMBLY

1. Insert stand shaft into pedestal.
2. To adjust height, loosen clamp wrench and bring down headstock to desired level and tighten clamp wrench.
3. Insert handle with knob into handle shaft.




RPM ADJUSTMENT

1. Unplug drill press
2. Open Headstock cover
3. Place belt as follows:

Top wheels	8500 RPM
Middle Wheels	6500 RPM
Bottom Wheels	5000 RPM

Headstock Cover

Belt



SAFETY WARNINGS

- Always wear proper eye protection when using the drill press.
- Never wear loose clothing when operating the drill press.
- Always operate with headstock cover attached.
- Keep long hair tied back when operating drill press.
- Always ground plug.
- Never alter or tamper with original equipment.