

NOVA RESIN BOND DIAMOND CARVING POINTS

Nova Points are designed to sand and polish carvings and other irregular shaped stones. They come in the same grits as our *Nova Wheels*. Good results may be achieved by using the standard sequence of 280-600-1,200-3,000. Additional steps such as 8,000 or 14,000 may be helpful when polishing some stones. *Nova Points* have a 3/32" shaft to fit most Foredom & Dremel hand power tools. *Nova Points* may show minor blemishes but this does not hurt their performance.

Instructions: *Nova Points* must be used with a lubricant, either water or *Gem Lube*. If they are run dry for even a short time, the resin can melt and the point will be ruined.

How you keep the *Nova Points* wet depends on the size of your workpiece. Small pieces can be sprayed with *Gem Lube* or dipped in a pan of water as you work. Larger pieces may require a sponge to keep the surface of the stone and the *Nova Point* wet. Just remember that the points and the workpiece must be kept lubricated.

Nova Points are color coded as follows:

GRIT	COLOR	GRIT	COLOR	GRIT	COLOR
60	Green	600	Brown	8000	Tan
140	Rust	1200	Grey	14000	Cream
280	Black	3000	Rose	50000	Lt Blue

WEAR SAFETY GLASSES WHILE USING NOVA POINTS
TO PROTECT YOU'RE EYES